


Diagram #	Part #	Description
1	T6009	Air cap ring
2	T6008	Air cap
3	T6002-1	Fluid nozzle
4	T6017	Fluid nozzle gasket
5	T6006	Air distributor plate
6	T6013	Fluid needle packing (4)
7	T6014	Fluid needle packing screw
8	T6002-1	Fluid Needle
9	T6003	Needle spring
10	T6004	Fluid adjusting screw
11	T6000-PARTS	Mist applicator body
12	T6016	Trigger pin
13	T6015	Trigger
14	T6010	Solution tube
15	A5402	Cup gasket
16	A5401	8oz. Cup



ApolloSpray T6000
Mist Applicator
Diagram & Parts List
760-727-8300
www.whisper-mist.com